

# BLOCKING MATERIALS

# BOND365™



Bond 365 Part A  
Bond 365 Part B



Uni-bloc Wood Block



Toe Cup



Toe Cup Holder



Mixing Sticks

### Helpful Hint:

Cold out? Keep Part B in your pocket and Part A in a warming bag prior to application. Bond365™ performs best between 65 - 75° F.

# APPLICATION INSTRUCTIONS

## STEP ONE



Dispense entire contents of Part A into toe cup.

## STEP TWO



Dispense entire contents of Part B into toe cup.

## STEP THREE



Mix the two parts vigorously with mixing stick for 25 seconds. Bond365 will turn opaque in color.

## STEP FOUR



When Bond365 becomes clear, insert block into bottom of toe cup.

## STEP FIVE



Apply thin layer to both block and claw. Spread remaining glue on block to ensure 3/16—1/4" (5-7 mm) thickness throughout.

## STEP SIX



Position block on prepared claw. Hold until Bond365 begins to harden. Reposition the block as needed. Allow to cure for four (4) minutes before weight bearing.